



The Clever Tether Laptop Alarm is the easy way to protect your laptop from theft via its USB port. If you need to leave your computer unattended for a moment, you can count on the Clever Tether to alert you if someone tries to steal it.

The eye catching cord and lock acts as a deterrent, so even the craftiest thief will stop and think twice about approaching your computer. The accompanying key features over 1,000,000 digital combinations, and is the only way to deactivate the alarm.







Insert the plug in the USB port



Remove the key for for deactivation or turn off the alarm)

- Just loop cord around any secure object
- Works while laptops are ON or OFF
- Alarm sounds if cord is cut or unplugged
- Master electronic key function



Specifications:	
Model:	P8280
Batteries (included):	3 x LR44
Cord Length:	60 inches
Dimensions:	2 1/2" diameter x 1"
Weight:	4 oz.

The best way to protect your laptop from being stolen using your USB