Operating Instructions P7600 Sol-Mate[®] Floating Light

Congratulations on your purchase of Sol-Mate[®] Floating Light. Please read these operating instructions thoroughly before use. It is important for proper use of the product.

The Sol-Mate[®] Floating Light offers gentle illumination to your water garden and adds a wonderful glow to your pool, birdbath, or even across your landscape.

WARNING

! Do not use indoors. Only use outdoors. !

! Do not leave the unit outdoors in extreme weather conditions. Temperatures below freezing can damage the unit. !

! Ensure the unit is closed and sealed securely before placing in water. !

! Only use NiMH batteries in unit. Other battery types may leak or explode. Do not use Carbon or Alkaline batteries. !

! Do not use the unit where it can interfere with pool or pond filtration equipment. !

! Do not use the unit where it can interfere with the safe ingress or egress to swimming areas. !

! Do not use the unit in any pool where diving is permitted. !

! Do not allow unit to travel into boating areas. !

Use:

- Unit is shipped with battery in place.
- Allow unit to fully charge before first use. Leave unit in direct sunlight for at least two sunny days. Leave switch in OFF position (button out) (factory default position).
- When ready to use unit push switch to ON position (button in).
- Place unit in water.
- Unit will charge when exposed to sunlight. Do not place unit in the shade or it will not recharge.
- If desired, anchor unit using anchor mount on base. Make sure rising tides or changing water levels will not flood unit. Damage may occur.
- LED Lamp will automatically turn on at dusk and turn off at dawn. Strong ambient light will prevent lamp from turning on.

Battery

- Unit is supplied with a quality 900 mAh Nickel Metal Hydride (NiMH) AA cell battery.
- Fully charged battery will yield up to 10 hours of light.
- Battery will charge when unit is exposed to sunlight. Strong direct sunlight will charge the battery faster.
- Battery is designed for up to 500 charge cycles. If you note reduced battery performance replace battery.
- Replace battery by unscrewing 3 phillips-head screws in base. Replace battery as specified below.
- Re-attach base ensuring battery is in position and rubber seal is in place.
- Ensure screws are tight or damage may occur. Do not over-tighten.
- Use only NiMH battery cells. Do not use Alkaline, Lithium, or Lithium Ion batteries. Incorrect batteries may leak or explode.
- NiMH batteries with less capacity than 900 mAh will yield shorter illumination times. You may use batteries with higher than 900 mAh capacity but the extra capacity will not be utilized.
- Ensure battery polarity is correct.

NOTE: Unit will charge battery regardless of switch position. ON/OFF switch only controls LED lamp. LED lamp will not illuminate when ambient light is too high.

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state

If you experience difficulty in the operation of your product, or if your product requires service please contact:

P3 INTERNATIONAL CORPORATION TECHNICAL SUPPORT **Tel: 212-741-7289** Fax: 212-741-2288

Email: techsupport@p3international.com

rev. 02/05