HOW TO OPERATE

- Slide and remove battery lid. Install two CR2032 batteries matching correct (+) or (-) poles as shown. Slide lid back into place.
- Switch unit on. Green light should appear on LED. If LED lights red, remove and replace batteries.
- When a wireless camera is discovered, LED will flash green and audio alarm will sound.



NOTE

- Do not bend or attach key chains or other items to unit.
- This unit detects radio signals from wireless cameras only. It cannot detect the presence of CCTV cameras or microphones.
- Remove batteries when unit will not be used for extended periods of time.
- Avoid placing unit in extreme temperatures. Do not get wet or drop.

P3 INTERNATIONAL • www.p3international.com

© 2001 P3 International Corporation.

Specifications subject to change without notice. Made in Taiwan