

Operating Manual
P8440
Smart Warmer Charger

Thank you for purchasing the P8440 multi-function Smart Warmer Charger. Slim and lightweight, you can carry it with you anywhere you need a convenient source of soothing heat. This unit will provide you with years of service if cared for properly. Please read these operating instructions thoroughly before use.

Features:

Warmer feature:

If your hands and fingers feel icy whether you're indoors or out, then our Smart Warmer Charger is for you. The Smart Warmer Charger has thermostatic controller inside which keep its shell surface warm.

Smart charger feature:

A compact eco-friendly charger helps you get an emergency charge for your cell phone.

Built-in light feature:

The built-in light feature comes in handy when you are in a dark place and need a little extra light.

How to Use:

Charging the unit:

Plug the USB cable into a computer, USB power socket or AC/Car Adapter to begin charging. A Red LED lamp will light up on the unit. Charging time depends on the power level of the power source.

When the Smart Warmer Charger is finished charging, the Red LED lamp will turn Green.

Charging your USB device:

You can use the Smart Warmer Charger to charge devices such as your cellphone. Plug the USB connector into the Smart Warmer Charger and the micro USB connector to a cellphone or other device. Check that a charging symbol appears on your phone screen.

Note: LED status in charging mode: 0-15% RED; 15-100% no light.

Warming:

Turn the 360° rotary switch to the "Warm" position to start heating the Smart Warmer Charger. A Green LED lamp will light up.

When the Smart Warmer Charger is low in power, the LED lamp will turn Red indicating to the user that it is time to recharge the unit.

To turn the Smart Warmer Charger off, turn the 360° rotary switch to the "Off" position. The LED light will shut off.

Note: LED status in warming mode: 0-15% RED; 15-100% no light.

Warming and Flashlight:

Turn the 360° rotary switch to "Warm/Light" position to start heating and the flashlight. A Green LED lamp will light up.

When the Smart Warmer Charger is low in power, the LED lamp will turn Red indicating the user to recharge the unit.

Note: LED status in warming/flashlight mode: 0-15% RED; 15-100% no light.

Flashlight:

Turn the 360° rotary switch to the "Light" position to start the flashlight. When the Smart Warmer Charger is low in power, the LED lamp will turn Red indicating the user to recharge the unit.

Caution

1. **Charge the Smart Warmer Charger fully before first use.**
2. **DO NOT drop, disassemble or attempt to repair the Smart Warmer Charger yourself.**
3. **Avoid exposure to water, high humidity, or any heat source.**

Specifications:

Model: P8440
Power Supply: Rechargeable by Micro USB port (5v/1000 mAh Max Input)
Built-in Battery: 3.7V 2200 mAh Lithium-ion Battery
Charging Time: 3.5 - 5 Hours
Warming Time: 4-5 Hours
Light Time: up to 50 Hours
Temperature: 104°F (40°C)
USB output: 5V. 1000 mAh max.
Dimensions: 7/8" x 4 5/8" (22x118 mm)
Weight: 3 oz.

Contents of Box: Smart Warmer Charger unit, USB to micro USB cable, and a Knit Sleeve case.

*Specifications subject to change without notice.

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION

TECHNICAL SUPPORT

Tel: 212-741-7289 Fax: 212-741-2288

Email: techsupport@p3international.com

Rev. 0813